

Rain Deflector (RD) Xtreme

Installation Instructions

RAIN DEFLECTOR FOR SEALS

(Right or left — read from outside facing building)

1. **INSTALL SEAL:** Follow the seal installation instructions.
2. **ATTACH HEAD BRACKETS TO THE WALL:** Use 1/2-inch or 3/8-inch anchors (not provided) to fasten the head brackets to the wall in the proper locations - typically 12-inches wider (overall) than the seal (the 1/4-inch back plate holes will have to be drilled out larger for this application). It is recommended to have the head frame at least 6-inches above the seal if possible. The peak of the headframe must be 15-feet off of grade. Make sure the brackets are even.
3. **ASSEMBLE RAIN PAD ONTO HEAD FRAME:** Remove aluminum angle from the frame. Position the pad on the frame and overlay the aluminum angle on top to align holes. Fasten angle, pad and frame together with lag screws provided (do not over tighten). Make sure to remove shipping blocks from the ends of headframe.
4. **MOUNT HEADFRAME TO WALL:** Place headframe on top of the head brackets with care taken to avoid damage to extended fiberglass section. At least three (3) anchors (not included) are recommended to mount to the wall - one in the middle and one within 12-inches of each end where possible. Use more if necessary.
5. **ATTACH SIDE FLAPS:** Use self-drilling screws to attach the side flaps to the head brackets. Ensure that the stay pocket is mounted to the front of the bracket.
6. **CAULK GAPS:** Caulk between the wall and headframe. If necessary, caulk under the aluminum angle. A silicone or butyl rubber caulk is recommended.

HARDWARE PROVIDED:

- Lag Screws
- Self-Drilling Screws

SUGGESTED MOUNTING METHODS

(Mounting anchors not included)


CONCRETE BLOCK OR BRICK WALL: Try to hit mortar joints. Use 1/2-inch or 3/8 x 4-inch expansion anchors. Use through-bolt fastening (minimum two per frame member) if anchors will not hold—3/8-inch threaded rod is recommended.

PRECAST CONCRETE: Same as above.

METAL SKIN BUILDING: Use through-bolt fastening as above, with a backup plate (steel or wood) to support bolts, or anchor through existing building girt or purlin when possible.

Rain Deflector (RD) Xtreme Installation Instructions

RAIN DEFLECTOR XTREME TYPICAL ARRANGEMENT



W194N11481 McCormick Dr. | Germantown, WI 53022
dlmdocks.com | sales@dlmdocks.com
800-643-5424

*Let DLM help you find the best
solution for your operation.*



dlmdocks.com

Designed, Engineered, and Manufactured in the U.S.A.
© 2025 Systems, LLC/DLM
Consistent with our policy of continuing product improvement, we reserve the right to
change product specifications without notice or obligation.

INSTALL INSTCNS RD 07/2025

A Division of Systems, LLC

**DLM DOCK LEVELER
MANUFACTURING**

Value Engineered Dock Levelers